















AREZZO ARBOUR

ASSEMBLY
INSTRUCTIONS



A	SIDE SECTIONS		2
B	SEAT BACK PANEL		2
C	SEAT		1
D	ROOF SECTIONS		2
E	ROOF FASCIA		4
F	FINIAL		2
G	ROOF COVER STRIP		1
T	Screw 3.5 x 30 mm		8
U	Screw 3.5 x 50 mm		8
V	Screw 3.5 x 70 mm		8
W	Screw 4 x 60 mm		10
X	Screw 4 x 90 mm		2
Y	Screw 4 x 120 mm		4
Z	Nails		4

CARE OF YOUR ARBOUR

The Arezzo Arbour is made of planed pressure treated and FSC certified timber and as such is guaranteed against rot for a minimum of 15 years. However, it must be remembered that as a natural product, timber is subject to movement and weathering as it seasons. It is not uncommon for small spits to occur when drying and warping when timber is allowed to dry too rapidly. These will normally go back when humidity rises, it is nature at work and not considered a fault.

Its colour will also change with time, a re-treatment, as required with a proprietary wood treatment is recommended.

Tools required (NOT SUPPLIED)

Power screwdriver with Pozidrive No.2 bit. Tape measure.
3mm pilot drill
Hammer.

Before you start.

Check the packs and make sure that you have all of the parts listed above. If not contact your retailer who will be able to help you.
When you are ready to start make sure you have the right tools to hand, plenty of space and a clean dry area for assembly.
It is advisable for two people to carry out the work.

ASSEMBLY

1. Take one of the side sections **A** and one of the back sections **B**. Fix the back panel to the side section using two screws **V**. Make sure the top of the panel is level with the top of the post of the side section as Fig 1..
2. Now fix the other side section to the back panel in the same way.
3. Turn the assembly on to the top end of the back panel and fix the remaining back panel between the posts ensuring it is firmly butted up to the fixed panel. Again use two screws either side as Fig 2.




Fig 2




Fig 3




Fig 4

7. There are fascia boards for the front and rear of the arbour. The straight edge should be fixed flush with the lower edge of the roof sections. Fix these in place using screws **T** as shown in Fig. 6
8. Fit the finials front and back as Fig 6 using screws **U**.
9. Finally, locate the roof cover strip **H** and nail in place with the nails provided.




Fig 1




Fig 6




Fig 5

4. Turn the assembly onto its back so that the seat may be fitted. Be sure to support the side sections during this step. Fix the seat in place as shown in Fig 3.
5. Next take the two roof sections **D** and screw together using screws **X** as shown in Fig 4.
6. Raise the roof onto the seat assembly and fix through into the top of the posts as shown in Fig 5.